

## ESW 7020

29 cm high handleless Gourmet warming drawer

for preheating crockery, keeping food warm and low temperature cooking.



- The ultimate in enjoyment – low temperature cooking
- Always at the right temperature – 4 functions
- Convenient and easy – Touch control
- Opening the drawer couldn't be easier – Push2open
- Better safe than sorry – timer function with automatic switch-off

EAN: 4002516169468 / Material number: 11093290 /  
Old Material Number: 30702020GB

Operating modes	
Cup warming	•
Plate warming	•
Operating modes	
Keeping food warm	•
Low temperature cooking	•
User convenience	
Push2open mechanism	•
Fully telescopic runners for easy loading and unloading of the warming drawer	•
Control panel with sensor controls	•
Timer function	•
Sabbath programme	•
Safety	
Cool front	•
Technical data	
Total rated load in kW	0.70
Voltage in V	230
Frequency in Hz	50-60
Fuse rating in A	10
Number of phases	1
Mains cable with plug	•
Length of supply lead in m	2.0
Accessories included	
Rack for increased capacity	1
Construction type and design	
Gourmet warming drawer	•
PureLine	•
VitroLine	•
ArtLine	•
Handleless	•
Appliance colour	Obsidian black
Convenience features	
Pre-heating crockery	•
Keeping food warm	•
Perfect cooking results at low temperature	•
User convenience	
Miele@home	•
Control panel with symbols	•
Stop programming	•
Efficiency and sustainability	
Power rating in off mode in W	0.3
Power rating in standby mode in W	0.8
Power rating in networked standby in W	2.0
Time until automatic switch to off mode in min	20
Time until automatic switch to standby in min	20
Time until automatic switch to networked standby in min	20

ESW 7020

29 cm high handleless Gourmet warming drawer

for preheating crockery, keeping food warm and low temperature cooking.



EAN: 4002516169468 / Material number: 11093290 /  
Old Material Number: 30702020GB

#### Cleaning and care

Flush control panel

•

#### Safety

Anti-slip mat

•

Safety switch-off

•

#### Accessory drawer

Capacity

12 place settings

#### Technical data

Temperatures min. in °C

40

Temperatures max. in °C

85

Appliance height in mm

289

Appliance depth in mm

570

Useable interior height in mm

230

Appliance width in mm

595

#### Accessories included


Anti-slip mat

1


## ESW 7020

29 cm high handleless Gourmet warming drawer


for preheating crockery, keeping food warm and low temperature cooking.



Installation DG, DGM, DGC XL, ESW7x20 installation drawings




side view, DG, DGM, ESW7x20 installation drawings




Installation, ESW7x20, DGM7x4x installation drawings


1) Front view, 2) Mains connection cable, L=2.000 mm, 3) Ventilation cut min. 180 cm², 4) No connection in this area




Installation DGC XXL, ESW7x20 installation drawings




ESW7020, Installation drawings, XL combination niche height



side view ESW7x20, installation drawing, GB, AU



built-in ESW7x20, installation drawing



Installation ESW7x20, installation drawing, GB, AU

1) Front view, 2) Mains connection cable, L=2.000 mm, 3) ventilation cut-out min. 180 cm², 4) no connection in this area